



- NOTES**
1. IF PILOT PTT SWITCH IS CONNECTED TO THE AIRCRAFT HAND MIC JACK, IT MUST BE DISCONNECTED AND CONNECTED TO THE WHITE / RED WIRE AS SHOWN.
 2. AIRCRAFT CHASSIS GROUND.
 3. SEE RADIO MANUFACTURERS INSTALLATION INSTRUCTIONS FOR ALL POWER, GROUND, AND ANY ADDITIONAL HOOKUPS.

Sport 200S - XCOM VHF760 Radio Installation Wiring Diagram

* ICS Load Modification. Add a 1/4 or 1/2 watt resistor per the drawing. The value of the resistor most commonly used is 220 ohms, however, optimum performance can be achieved by selecting the value right for your particular installation. The resistor can be any value between 100 and 1000 ohms and is selected for the best balance between radio receive volume and intercom volume. For more information about this resistor mod see the ICS Load Modification instructions. File Name: ICS-Load_1440_Mod.pdf

