

The headset parts may be cleaned with mild soap and water using a soft cloth. Then dry immediately. **Caution: Do Not immerse** any part of the headset in water or any other liquid. Be especially careful not to allow the microphone to become wet! Exposure to moisture may cause internal corrosion and failure and will void your manufacturers warranty.

Cleaning will help the headset maintain its "like new" condition for many years.

WINDSCREEN

The microphone windscreen will reduce annoying wind noise and breath pops picked up by headset microphones. It also protects the microphone element from dirt and moisture. The windscreen should be washed regularly to maintain hygiene and avoid clogging. Wash in warm water and mild soap. Rinse thoroughly and make sure it is completely dry before putting it back on.

To remove the windscreen, take out the screw that holds the microphone on the boom and grasp the windscreen lightly along its entire length and slip it off.

Put the windscreen on the microphone by gently pulling from the open end. Do not pull it so tightly that it stretches against the end of the microphone.

WARRANTY

Your headset is covered by a limited one-year parts and labor warranty. Please see the enclosed warranty card for details.

You may refer to the parts list on the reverse side, if you choose to replace parts yourself. The parts list describes parts for this particular headset only. Parts lists for other models are available on our Web Site or can be obtained by contacting Sigtronics Corporation.



Sigtronics Corporation
178 East Arrow Highway
San Dimas, CA 91773
Phone: 909 305-9399
E-mail: info@sigtronics.com
Web Site: www.sigtronics.com

Model SE-40RPTT Headset Instructions

The SE-40RPTT series headset is adjusted at the factory for immediate use. The headset is equipped with a single plug and a coiled cord.

The headband is adjustable through a full range of motion, and the locking nuts may be tightened to allow you to custom fit the headphone. Place the headphone over your head and adjust the slides up until minimum pressure is felt on the top of your head. For maximum noise attenuation, the clamping pressure of the headband has been set at the factory. Releasing the clamping pressure by bending the headband is **not advised**, because loss of attenuation will result.

The microphone boom is fully adjustable and will rotate 180 degrees for use on the left or right side of the head. The locking screw that secures the boom to the ear cup is factory set to insure the correct tension. Turning it will not change the tension, because the nut on the inside of the cup will turn as well.

Microphone placement should be at the corner of the mouth, approximately ¼" from the lips. The exclusive thumb screw on the mic boom may be used to assure proper placement.


Your SE-40RPTT headset has a push to transmit switch located on the mic side ear cup. When the headset is connected to a radio, depressing this switch will cause the radio to transmit. The switch is **not used** for intercom function.

When you **first connect the headset**, turn the volume control on the headset up to the full clockwise position, then adjust the listening volume with the audio control of either your radio or intercom as appropriate. If applicable, crew members should also turn their individual headset volumes up fully. Doing this allows for a full range of adjustment for each passenger, since those with the most acute hearing can turn their headset volume down, if necessary.



...when it counts!

continued on back...



SIGTRONICS SE-40RPTT HEADSET PARTS IDENTIFICATION BREAKDOWN

ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION
1	100049	GROMMET, 5/16 INCH, RUBBER	16	100369	EAR SEAL, FOAM FILLED	31	800039	CABLE, MICROPHONE BOOM, 12 INCH
2	100063	KNOB, 3/8 INCH, BLACK	17	100370	RECEIVER MOUNT, HEADSET	32	800048	HEADBAND , WITH CUSHION, SE-40
3	100077	POTENTIOMETER	18	100221	WIRE, #22, 19 STRAND, 4 INCH	33	800082	MICROPHONE, ELECTRET, M-80
4	100079	RECEIVER, 300 OHM, MONO	19	100373	SLIDE, YOKE BRACKET, LONG, NYLON	34	100569	STRAIN RELIEF, CABLE
5	100108	SCREW, 4-40 X 1/4, THREAD FORMING	20	100374	FOAM, SOUND ATTENUATING. NOTCHED, 1/2 INCH	35	100156	SCREW, THUMB, MICROPHONE BOOM, 2-56 X 1
6	100249	BOOM, ELECTRET MICROPHONE SUPPORT, SWIVEL	21	100376	FOAM, SOUND ATTENUATING. RECEIVER HOLE, 1/2 INCH	36	900084	WINDSCREEN, MICROPHONE, FOAM, PACKAGED
7	100251	E-RING, EAR CUP TO YOKE RETAINER	22	100379	FOAM, SOUND ATTENUATING, RECEIVER COVER, 1/4 INCH	37	100415	WINDSCREEN, MICROPHONE, FOAM, BULK
8	100252	NUT, HEX, 8-32, LOCKING	23	100366	WIRE, 2 CONDUCTOR, #24, BLACK, 28 INCHES	38	100232	SWITCH, SPDT, MOMENTARY
9	100361	EAR CUP, PRINTED AND DRILLED, MIC & NON MIC SIDE	24	100258	CLIP, HEADBAND GUIDE, PLASTIC	39	100625	O-RING, PTT, HEADSET
10	100362	CLIP, CROSS-OVER, WIRE, PLASTIC	25	100393	CLIP, ANTI-ROTATION, YOKE, PLASTIC	40	100428	SWITCHGUARD, PTT, BLACK
11	100363	SCREW, 8-32 X 1/2, PHILLIPS HEAD	26	100602	HEADBAND, METAL, STANDARD, BLACK	41	100317	BUTTON, SWITCH, PTT, RED
12	100364	SCREW, 8-32 X 3/8, PHILLIPS HEAD	27	100604	BRACKET, YOKE SUPPORT WITH TANG, BLACK	42	100613	OPTIONAL - HEADBAND, METAL, LARGE, BLACK
13	100377	SCREW, 8-32 X 5/8, PHILLIPS HEAD	28	100385	WASHER, SPRING, BOOM ADAPTER	43	100402	OPTIONAL - EAR SEAL, GEL FILLED
14	100603	YOKE, EAR CUP MOUNT, METAL, BLACK	29	100408	WASHER, GROOVED BOOM			
15	100368	KNOB, MICROPHONE BOOM ADAPTER, PLASTIC	30	800046	CABLE, HEADSET, COILED			