The headset parts may be cleaned with mild soap and water using a soft cloth. Then dry immediately. ***Caution: Do Not immerse*** any part of the headset in water or any other liquid. Be especially careful not to allow the microphone to become wet! Exposure to moisture may cause internal corrosion and failure and will void your manufacturers warranty.

Cleaning will help the headset maintain its "like new" condition for many years.

WINDSCREEN

The microphone windscreen will reduce annoying wind noise and breath pops picked up by headset microphones. It also protects the microphone element from dirt and moisture. The windscreen should be washed regularly to maintain hygiene and avoid clogging. Wash in warm water and mild soap. Rinse thoroughly and make sure it is completely dry before putting it back on.

To remove the windscreen, carefully grasp the windscreen lightly along its entire length and remove from the microphone element being careful not to twist the element itself.

Put the windscreen on the microphone by gently pulling from the open end. Do not pull it so tightly that it stretches against the end of the microphone.

WARRANTY

Your headset is covered by a limited two-year parts and labor warranty. Please see the enclosed warranty card for details.

You may refer to the parts list on the reverse side, if you choose to replace parts yourself. The parts list describes parts for this particular headset only. Parts lists for other models are available on our Web Site or can be obtained by contacting Sigtronics Corporation.

Sigtronics Corporation
178 East Arrow Highway
San Dimas, CA 91773
Phone: 909 305-9399
E-mail: info@sigtronics.com
Web Site: www.sigtronics.com

Model SE-48SRPTT Headset Instructions

The SE-48SRPTT series headset is adjusted at the factory for immediate use. The headset is equipped with a single plug and a coiled cord.

The headband is adjustable through a full range of motion, and the locking nuts may be tightened to allow you to custom fit the headphone. Place the headphone over your head and adjust the slides up until minimum pressure is felt on the top of your head. For maximum noise attenuation, the clamping pressure of the headband has been set at the factory. Releasing the clamping pressure by bending the headband is ***not advised***, because loss of attenuation will result.

The microphone boom is fully adjustable and will rotate 180 degrees for use on the left or right side of the head.

Make sure you are speaking into the side of the mic labeled "Talk" or substantial loss of gain will occur. Microphone placement should be at the corner of the mouth, approximately ¼" from the lips.

Your SE-48SRPTT headset has a push to transmit switch located on the mic side ear cup. When the headset is connected to a radio, depressing this switch will cause the radio to transmit. The switch is ***not used*** for intercom function.

When you ***first connect the headset***, turn the volume control on the headset up to the full clockwise position, then adjust the listening volume with the audio control of either your radio or intercom as appropriate. If applicable, crew members should also turn their individual headset volumes up fully. Doing this allows for a full range of adjustment for each passenger, since those with the most acute hearing can turn their headset volume down, if necessary.

continued on back…

Sigtronics®

…when it counts!



SIGTRONICS SE-48SRPTT HEADSET PARTS IDENTIFICATION BREAKDOWN

ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION	ITEM	P/N	DESCRIPTION
1	800197	HEADBAND , WITH CUSHION, SE-48	**14**	100962	EAR CUP, SLOTTED, PRINTED, NON-MIC SIDE	**27**	100935	WIRE, #22, JUMPER, HEADSET, 4 INCH
2	100602	HEADBAND, METAL, STANDARD, BLACK	**15**	800193	MICROPHONE & FLEX BOOM ASSEMBLY	**28**	100569	STRAIN RELIEF, CABLE
3	100603	YOKE, EAR CUP MOUNT, METAL, BLACK	**16**	100597	NUT, HEX, 3/8-24, FLEX BOOM ADAPTER	**29**	100063	KNOB, 3/8 INCH, BLACK
4	100604	BRACKET, YOKE SUPPORT WITH TANG, BLACK	**17**	100611	WINDSCREEN, MICROPHONE, FOAM, BULK	**30**	100077	POTENTIOMETER
5	100373	SLIDE, YOKE BRACKET, LONG, NYLON	**18**	900111	WINDSCREEN, MICROPHONE, FOAM, PACKAGED	**31**	100858	RECEIVER AND MOUNT, 300 OHM, MONO
6	100258	CLIP, HEADBAND GUIDE, PLASTIC	**19**	100612	O-RING, WINDSCREEN RETAINER, SE-48	**32**	100232	SWITCH, SPDT, MOMENTARY
7	100393	CLIP, ANTI-ROTATION, YOKE, PLASTIC	**20**	800192	PREAMP	**33**	100625	O-RING, PTT, HEADSET
8	100363	SCREW, 8-32 X 1/2, PHILLIPS HEAD	**21**	100369	EAR SEAL, FOAM FILLED	**34**	100428	SWITCHGUARD, PTT, BLACK
9	100364	SCREW, 8-32 X 3/8, PHILLIPS HEAD	**22**	100684	FOAM, SOUND ATTENUATING, FOR SLOTTED EAR CUP ONLY	**35**	100317	BUTTON, SWITCH, PTT, RED
10	100108	SCREW, 4-40 X 1/4, THREAD FORMING	**23**	100374	FOAM, SOUND ATTENUATING. NOTCHED, 1/2 INCH	**36**	100613	OPTIONAL – HEADBAND, METAL, LARGE, BLACK
11	100251	E-RING, EAR CUP TO YOKE RETAINER	**24**	100376	FOAM, SOUND ATTENUATING. RECEIVER HOLE, 1/2 INCH	**37**	100402	OPTIONAL – EAR SEAL, GEL FILLED
12	100252	NUT, HEX, 8-32, LOCKING	**25**	100379	FOAM, SOUND ATTENUATING, RECEIVER COVER, 1/4 INCH			
13	100952	EAR CUP, PRINTED AND DRILLED, MICROPHONE SIDE	**26**	800046	CABLE, HEADSET, COILED			