


Engine Single Radio System US-45S Intercom



The jack and switch at the Pump Panel are paralleled with the jack and switch in the cab. Only one headset can be plugged in at a time. In this example either the Engineer or Pump Panel headset position.

This example is for a system using a **US-45S** UltraSound Intercom with optional Mobile Radio Y-Adapters (if necessary).

This system will support up to 4 headset positions simultaneously with 2 of the positions having transmit capability on one radio.

US-45S UltraSound Intercom

- Single Radio
- Up to 4 Headset Positions
- 2 Radio Transmit Positions

SE-8 Headsets

- Standard Dual Ear Cup, Flex Mic Boom

Mobile Radio Y-Adapter

- Only necessary for some mobile radio models.
- Y-Adapter model depends on the model of radio.

Clear Communication 
EVERY TIME

Sigtronics Corporation

San Dimas, California

Phone: (909) 305-9399

E-mail: info@sigtronics.com

Web Site: www.sigtronics.com