


**Engine Dual Radio System**  
**SWS-6 Wireless System**  
**US-67D Intercom**



Wireless Headset  
 Use as an **additional** headset position or in place of any headset position.

SWB-6  
 Wireless Headset  
 Module

Radio Push-To-Transmit Switch (RPTT)

Engineer  
 SE-8 Headset

Officer  
 SE-8 Headset

Crew  
 SE-8 Headset

Crew  
 SE-8 Headset

Crew  
 SE-8 Headset

Crew  
 SE-8 Headset

The jack and switch at the Pump Panel are paralleled with the jack and switch in the cab. Only one headset can be plugged in at a time, either the Engineer position or Pump Panel.

This example is for a system using a **US-67D** UltraSound Intercom with optional SWS-6 Wireless system and Mobile Radio Y-Adapters (*if necessary*).

This system will support 1 wireless headset and up to 6 wired headset positions simultaneously with 4 of the positions having transmit capability on two radios.

Headset Jack with Splash Cover

**UltraSound Intercom**

- Dual Radio, up to 7 Positions, 4 Transmit Positions: **US-67D**

**SWS-6 Wireless Headset & Interface Module**

- Dual Ear Cup, Flex Mic Boom, Wireless

**SE-8 Headsets**

- Standard Dual Ear Cup, Flex Mic Boom

**Mobile Radio Y-Adapter**

- Only necessary for some mobile radio models  
 Y-Adapter model depends on the model of radio

*Clear Communication*  
**EVERY TIME**

**Sigtronics Corporation**

San Dimas, California

**Phone:** (909) 305-9399

**E-mail:** info@sigtronics.com

**Web Site:** www.sigtronics.com